


# OWNER'S OPERATION MANUAL


Econo Recirculating Controller Installation and Operating Instructions

#### MODEL: RAM-30002-TC




## **INSTALLATION**

#### MOUNTING



- 1. Controller enclosure must be mounted in a vertical position.
- 2. Ensure mounting method does not compromise enclosure weather proof rating.
- Ensure cables/conduits entering the panel have mechanical protection and that the penetrations are sealed and do not compromise the weather proof rating of the enclosure.

#### CONNECTION



### SETTING UP MATELEC TIME CLOCK

#### COM- 30314

1. To start switch, press Reset key

3. Programming steps as follows:

2. To adjust the present time, please press  $\Theta$ 

key, then press D+, H+, M+ to adjust the Days, Hours and Minutes.



Step	Кеу	Programming
1	Press P	Setting 1 ON time (display 1 on)
2	Press H+/M+	Setting hours and minutes
3	Press D+	Select same everyday, different day, MO-FR, MO-SA, SA-SU, MO WE FR, TU THU SA, MO-WE, TH-SA. (if same everyday, no need to press this key)
4	Press P	Setting 1 OFF time (display 1 off)
5	Press H+/M+	Setting hours and minutes of the turn off time
6	Press D+	If you want the same setting every day, there is no need to press this key
7	Repeat steps 2~6	Set 2-17 ON/OFF times
8	Press 🕒	End

### **OPERATION**

- Weatherproof Poly Enclosure
- Pump 240Vac 6Amp (MAX)
- Auto/Manual Selection
- Mounting Brackets Included

√ CB1					
Circuit Breaker					
•					TC1 A10 A2 7 Day Time Clock
					TC2 A10 A2 7 Day Time Clock
	S1 Pump 1 Man Auto Pump 2 Man	TC1 <u>4</u> 5 NO Contact	TC23 4 Ls Timer Contacts	Earth Active Neutral	P1 240VAC Pump P2 240VAC Pump
					rump