

ASCENTO GROUP AUSTRALIA

ABN 20 527 073 843 37 Export St Lytton QLD 4178 07 3893 5000 csv@ascento.com.au www.reefe.com.au

PRESSURE SWITCH WITH SPDT CONTACT RMP SERIES


INSTRUCTION MANUAL


MODEL: RMP5 - CONTROL | RMP12 | RMP16 **CODE:** 35801 | 35252 | 34910

TECHNICAL DATA	RMP5 35801	RMP12 35252	RMP16 34910
Max Working Pressure	5	12	16
Setting Range	0,9-5,0	2,5 - 10,0	2,5 - 12,0
Minimum Differential	0,4	0,8	0,8
Maximum Differential	2,5	1,4	3,8
Maximum Load	5A 250V ~	5A 250V ~	5A 250V ~

Optional - Adjustable Differential

IP55





SETTING

- A. Turn differential nut (1) up completely
- B. Adjust Range Nut (2) to desired commutating value of the contact
- C. Adjust the differential by turning the relevant nut (1)

NB: Set the inlet of power cables toward the floor.

2 Year Warranty applies **

**All warranties subject to the current version of the Ascento Standard Terms & Conditions of Warranty which can be found by navigating to www.reefe.au and searching "Warranty"